

How-to Use Acrobat HD Mini

Plug power cord into Acrobat, and into a power outlet

Click the power button below the screen/Enhanced Vision logo

The camera head should be turned to the right of the neck for proper orientation

To read something close up: Aim the camera down, with the lid closed

To read something further away: Aim the camera at the target, remove the lid, and Zoom In on the target

To change color enhancements: Click the mode button on the camera

[User Manual \(Online PDF \[English\]\)](#)

